




User Manual



SHUTTER WALL

Art. nr:

515431

515432

515433



English

ACCESSORIES NEEDED

Work gloves

Knife or cutter

Cordless screwdriver & impact drill

Suitable drill bits

Deutsch


BENÖTIGTES ZUBEHÖR

Arbeitshandschuhe


Messer oder Cutter

Akkuschrauber & Schlagbohrmaschine


Passende Bohrer




A x1




B x1




C x2



D x4



E x4



F x2




G x4










1



B x1




F x2





2






A x1



C x2







G x4





3








4



D x4



Draw lines, drill holes, tap in plastic expansion pipe.


If the floor is a wood floor, you don't need to knock in the plastic expansion pipe, directly use E to knock in the floor

Zeichnen Sie Linien, bohren Sie Löcher und klopfen Sie das Kunststoff-Dehnungsrohr ein.

Wenn der Boden ein Holzboden ist, brauchen Sie das Kunststoffausdehnungsrohr nicht einzuschlagen, sondern verwenden Sie direkt E, um den Boden einzuschlagen.




E





5



E x4

